

## Customer Return Materials Authorization Form

Instructions:

- 1.) Call or E-Mail Atmosphere Engineering to assign an RMA number for your return
- 2.) Fill out form
- 3.) Print and include this document with your returned units. **Orders that arrive without an RMA form will require additional time to process.**

---

RMA#: \_\_\_\_\_ Company \_\_\_\_\_ Contact Name \_\_\_\_\_

Date Shipped to AEC \_\_\_\_\_ E-Mail Address \_\_\_\_\_ Phone Number \_\_\_\_\_

Item Return Address \_\_\_\_\_

Preferred Return Shipping Method  
(UPS or FedEx Account Number)

---

Model/Part#/Quantity \_\_\_\_\_

Serial Number(s) if known \_\_\_\_\_

Reason for Return \_\_\_\_\_

Service Required

Repair

Credit

Evaluation Only

Recalibration/Resize

Return Time Requested

Standard Time

Expedite

(\$100 fee will be added to order)

---

### For Internal Use Only

Return Received On:

Return Received By: